

Resetting the Cisco switch.

```
flash_init
```

```
dir flash:
```

```
delete flash:vlan.dat
```

```
delete flash:private-config.text
```

```
delete flash:multiple-fs
```

```
delete flash:config.text
```

```
boot
```